

Part Number	Description	G17 Gen 1-3 9mm	G17 Gen 4 9mm	G17 Gen5 9mm	G19 Gen 2-3 9mm	G19 Gen 4 9mm	G19 Gen 5 9mm	G19X 9mm	G26 Gen 2-3 9mm	G26 Gen 4 9mm	G26 Gen 5 9mm	G43 9mm	G20 Gen 4 10mm	G29 Gen 4 10mm	G40 Gen 4 MOS 10mm	G21 Gen 4 .45 Auto	G30 Gen 4 .45 Auto	G36 .45 Auto	G41 Gen 4 .45 Auto	G45 Gen 5 9mm	On Hand
BARRELS																					
32001	Barrel G17 9mm Fits Gen 4 and prior	X	X																		
3633	Barrel G17L 9mm																				
38486	Barrel G17 Gen 5 9mm			X																	
3577	Barrel G19 9mm (for use in slides produced prior to CHP)				X																
6997	Barrel G19 9mm VAR1 (for use in CHP or newer production VAR1 slides ONLY)				X	X															
42707	Barrel G19Gen5, G19X, G45, 9mm						X	X												X	
6012	Barrel G26 9mm								X	X											
43639	Barrel G26 Gen 5 9mm										X										
37593	Barrel G43 & G43X 9mm											X									
5355	Barrel G20 10mm												X								
8623	Barrel G29 10mm													X							
5355	Barrel G40 10mm														X						
5362	Barrel G21 .45 Auto															X					
8637	Barrel G30 .45 Auto																X				
1872	Barrel G36 .45 Auto																	X			
32470	Barrel G41 .45 Auto																		X		
CONNECTOR																					
721	4.5 lb "minus" (marked " - ") - LE agency ONLY (Chief or Sheriff Authorization & Signature required) - See page 12 (Excludes G42, G43)	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o
343	5.5 lb "standard" (no marking)	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
7965	5.5 lb "#5 Gen4 & Gen5" (marked ".") Includes G44, G45, G45MOS	o	X	X	o	X	X	X	o	x	x	X	X	X	X	X	X	X	X	X	X
735	8 lb "plus" (marked "+")	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o	o
33564	5.5 lb "standard" G42, G43, G43X, G48 (marked "-")											X									
33847	8 lb "plus" (marked "+")											X									
EXTRACTORS and SPRING LOADED BEARINGS																					
1895	Extractor 9mm, .380 (15 degree) with Loaded Chamber Indicator (LCI) (use only with 2714 Bearing)	X	X		X	X			X	X										X	
33774	Extractor 9mm G17Gen5,G19Gen5,G19X,G26Gen5,G34Gen5MOS,G45,G45MOS (Use with 3449 EDP Assembly or 2714 Bearing ONLY)			X			X	X			X									X	
33376	Extractor 9mm Slim (15 degree - 0 degree) with Loaded Chamber Indicator (LCI) - G43,G43X,G48 Only											X									
2714	Spring-Loaded Bearing - black - 9mm & 380 (use only with above LCI Extractors) (Includes All Gen5,G19X,G45) (Excludes G42,G43, G43X,G48)	X	X	X	X	X	X	X	X	X	X									X	
98	Extractor 9mm (90 degree) - non-LCI for older slide with 90 degree ejection port - (use with 1176 bearing)	X							X												
1176	Spring-Loaded Bearing - black - for 9mm and .380 with non-LCI extractor (do not use with LCI extractor)	X							X												
1909	Extractor 10mm (15 degree -5 degree) G20,G29 - with Loaded Chamber Indicator (LCI) (use only with 3442 Bearing)												X	X							

